Q4 audio

GE134 SINGLE 1/3 OCTAVE GRAPHIC EQUALISER

GE234 DUAL 1/3 OCTAVE GRAPHIC EQUALISER

USER MANUAL

Thank you for choosing this GE series graphic equaliser for your application. You have made an excellent choice.

The GE series are designed and built to be the most versatile analog graphic processors available.
The combination of a full featured graphic equaliser with high and low pass and shelving filters provides full control to even the most exacting user.

The dynamics trim control and the 8 segment level/peak meter provide headroom optimisation of the signal path. This unique feature makes it possible to reduce the noise floor of the unit by as much as 12dB, making the equaliser virtually dissapear in critical applications.
If a higher noise floor is acceptable, this control can create an extra 12dB of headroom for the filter circuits, thereby minimising distortion and clipping.

The autoranging power supply of the GE series guarantees trouble free operation of these units all over the world, independent on local mains conditions.

You probably want to start working with this new equipment right away and not read all of the information inside this manual.
For those of you who are in a hurry, please read the safety instructions carefully. Also the information about the DYN control, a unique feature of these units, will be very enlighting.

Because of the apparent similarities between the GE134 and the GE234, both are covered together in this manual.

Summit Engineering nv
Q4audio division
Tongersesteenweg 190
3800 Sint Truiden
Belgium
tel: +32 11 69 42 59
fax: +32 11 69 45 92
www.Q4audio.com
email: info@Q4audio.com

SE Part Number: 17000-00041
Rev. B

Q4audio is a registered trademark of Summit Engineering nv
All other trademarks are property of their respective owners

Explanation of grahical symbols:

This symbol is intended to alert the user of presence of uninsulated dangerous voltage within the products enclosure that may be of sufficient magnitude to constitute risk of electric shock to persons.

This symbol is intended to alert the user of presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

Explication des symboles graphiques:

Ce symbole doit alerter l'utilisateur du danger provenant d'un voltage dangereux et non protégé à l'intérieur de l'appareil, voltage suffisamment fort pour représenter un danger réel d'électrocution.

Ce symbole doit attirer l'attention de l'utilisateur sur les instructions importantes qui concernent le service et la maintenance et qui accompagnent tout appareil.

Erklärung der Bildsymbole:

Dieses Symbol warnt den Benutzer vor nicht isolierter gefährlicher Spannung im Inneren des Gerätes. Diese Spannung ist hoch genug um Personen durch elektrischen Schlag zu gefährden.

Dieses Symbol weist den Benutzer auf wichtige Bedienungs- und Wartungsanweisungen hin die in den gerätebegleitenden Unterlagen aufgeführt werden.

Note:

This equipment has been tested and found to comply with EN55103-1 and EN55103-2 product specifications. These product specifications are designed to provide a reasonable protection against harmful interference. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions, can cause harmful interference. There is no guarantee that interference will not occur in a specific installation. If harmful interference is detected try and correct it by one of the following measures:

- Increase the separation between the equipment.
- Connect the equipment to different mains outlets.
- Reroute cables.

CAUTION: To reduce the risk of electric shoc, do not open. No user-serviceable parts inside. Refer servicing to qualified personnel.

WARNING: To prevent fire or electric shoc, do not expose this equipment to rain or moisture.

ATTENTION: Pour éviter les risques de choc électrique, ne pas ouvrir. Cet appareil ne comporte aucune pièce pouvant être réparée par l'utilisateur. Confier l'entretien à un technicien qualifié.

AVERTISSEMENT: Pour éviter les risques de choc électrique ou d'incendie, n'exposez cet appareil ni à l'humidité ni à l'eau (pluie...).

ACHTUNG: Um Gefährdung durch elektrischen Schlag zu vermeiden darf das Gerät nicht geöffnet werden. Es befinden sich keine vom Benutzer reparierbaren Teile im inneren des Gerätes.Jegliche Reparatur soll einem qualifizierten Fachmann uberlassen werden.

WARNUNG: Um die Gefahr eines Feuers bzw. eine Verletzung durch elektrischen Schlag zu vermeiden sollte das Gerät niemals Regen oder Feuchtigkeit ausgesetzt werden.

Safety Instructions

1. **Read Instructions** - All safety and operating instructions should be read before this unit is put into service.
2. **Keep instructions** - The safety and operating instructions should be retained for future reference.
3. **Observe Warnings** - All warnings on the unit and in this operating manual should be strictly followed.
4. **Water and Moisture** - This unit should not be used near water - for example, near bathtub, washbowl, kitchen-sink, laundry tub, in a wet basement, near a swimming pool or the like.
5. **Heat** - This unit should be placed away from heat sources, such as radiators or other devices which produce heat.
6. **Power cord protection** - The power supply cord should be routed so that it is not likely to be stepped on or pinched by objects placed on or against them.
7. **Non-use periods** - The power cord of the unit should be unplugged from the outlet when the unit is not used for a longer period.
8. **Object and liquid entry** - Care should be taken so that objects do not fall and liquids are not spilled into the inside of the unit.
9. **Damage requiring service** - Unplug the unit and refer servicing to qualified service personnel under any of the following conditions:

   •Objects have fallen, or liquid has been spilled into the unit.
   •The unit has been exposed to rain.
   •The unit does not appear to operate normally or exhibits a marked change in performance.
   •The unit has been dropped, or its chassis damaged.
   •The power cord or plug is damaged.

10. **Servicing** - The user should not attempt to service the unit beyond those means described in this operating manual. All other servicing should be referred to qualified personnel.
11. **To prevent fire or electric shock** - Only use the polarised mains plug option together with a polarised receptacle. This unit is equipped with a single pole disconnect device (fuse) in the phase (live) wire. If an unpolarised mains connection is used the receptacle the unit is connected to must be equipped with a two pole disconnect device (fuse) of appropriate rating.
12. **Grounding and mains polarisation** - Precautions should be taken so that the grounding and mains polarisation means of the unit are not defeated.
13. **Ventilation** - Slots and openings in the unit are provided for ventilation, to ensure reliable operation and to prevent overheating of the unit. These openings should not be blocked or covered!

The Front Panel



1. Sliders to cut or boost the individual 1/3 octave frequencies of the graphic equaliser.
2. 'Graphic section' switch with control led enables or disables the graphic equaliser. Even in bypass mode, the level and clip detection keeps monitoring the graphic equaliser's circuitry for overload conditions.
3. '6 dB scale' switch with control led to alter the cut and boost range of the graphic equaliser from 12dB to 6 dB.
4. High Pass frequency adjustment. Adjustment range is 15Hz* to 300Hz*.
5. 'HP' switch with control led to turn HP filter on or off.
6. 'LP' switch with control led to turn LP filter on or off.
7. Low Pass frequency adjustment. Range is 2KHz* to 40KHz*.
8. Low Frequency Shelving filter control. Enables tilting the low frequency range by ±6db.
9. High Frequency Shelving filter control. Enables tilting the high frequency range by ±6dB.
10. 'Power' led indicates when mains power is connected to the unit.
11. 'Measuring point' switch selects monitoring of input, output

or maximum signal level. During operation the switch should be in the MAX position, indicating the maximum signal level of all possible overload points inside the unit. Time constants are chosen for easy read-out and comfortable adjustment of the DYN control.

The INPUT and OUT positions enable overall gain adjustment of the unit and should only be used temporarily while adjusting the equaliser. Response time of the display is very fast in this mode to avoid delay.

12. Headroom meter and a clip indicator. The headroom indicator is an average calibrated peak meter that indicates headroom in dB from clipping level. The clip led lights at +20dBu (0 dBu is 0.7746V). The absolute overload point of the unit is at +21dBu. The clip led gives accurate indication of overload conditions inside the unit, independent of the 'measuring point' switch position.

13. 'Bypass All' switch with control led to bypass the complete equaliser. By pressing this knob, the input is directly linked to the output by means of a the fail-safe relay. When the power to the unit is removed, the unit automatically switches to this bypass mode.

14. Dynamics control knob. This control enables levelling of the signal inside the equaliser. By turning the control anticlockwise (low noise position) the signal is amplified at the input and attenuated at the output. This increases the signal level in the equaliser electronic circuits and improves the signal to noise ratio by as much as 12dB. Use the headroom indicator as a read-out of the maximum signal level in the unit's circuits to adjust this control.

Turning the DYN control clockwise will reduce the input gain and at the same time increase output gain, to keep overall gain constant. As a consequence, the input signal level to the filters is lowered, giving more headroom at the expense of an increased noise floor. Because the headroom indicator measures signal level at every critical point in the equaliser, therefore also at the output, turning the DYN control clockwise will not always show up on the headroom indicator. Reason is that the output level remains the same and decreasing the signal level in circuits that precede the output is not sensed by the headroom indicator.

The true virtue of the clockwise DYN range becomes apparent when some filters in the unit are masked by others. For instance, when the shelving controls are used to boost a range of frequencies while the graphic equaliser is used to cut a specific range of these frequencies. In such case it can be important to reduce the signal level in the shelving filters to accommodate the boost and avoid clipping of the these filters. In this case the gain in headroom is clearly indicated by the level meter because the measuring point at the shelving filters in not 'masked' by the output measuring point because the graphic equaliser that follows the shelving filters in the signal path, attenuates the output level.

Changing the DYN control position does not change overall gain of the unit (smaller than ±0.5dB of overall gain change over the entire control range).

15. 'Gain' control knob to adjust overall gain between -12dB and +12dB. 16. Four M4 screws fix the 19" bracket ornamental parts. In case a security cover is mounted, these mounting positions are used to fix the security cover.

*** Note:** Although high quality carbon polymer potentiometers are used in this unit, absolute calibration accuracy of these controls is only modest. Indicated values on the front panel represent average numbers collected from several production lots. Actual values can differ by as much as 20% from the indicated values.

The Rear Panel


www.Q4audio.com
Q4audio IS A PRODUCT OF SUMMIT ENGINEERING NV
MADE IN BELGIUM, EU
Model: GE 134
Serialnr.: GE134-02AA-0001
Date of manufacture: 28.08.02
Made in Belgium, EU
Power requirements: 85-264V AC 50/60Hz 12W
FUSE: T 315 mA / 250 V
PUSH
INPUT IMPEDANCE: 20K BALANCED 10K UNBALANCED
INPUT
GND
OUTPUT
OUTPUT IMPEDANCE: 100 OHM BALANCED 50 OHM UNBALANCED
NOTICE: SYSTEM CONNECTOR USES PROPRIETARY FORMAT. REFER TO USER MANUAL BEFORE MAKING CONNECTIONS.
SYSTEM CONNECTOR
AVIS
RISQUE DE CHOC ELECTRIQUE NE PAS OUVRIR
CAUTION
RISK OF ELECTRIC SHOCK DO NOT OPEN
WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK DO NOT EXPOSE THIS EQUIPMENT TO RAIN OR MOISTURE. NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED PERSONNEL.
READ INSTRUCTION MANUAL CAREFULLY BEFORE USE.
ATTENTION: AFIN DE REDUIRE LE RISQUE DE CHOC ELECTRIQUE, NE PAS EXPOSER A LA PLUIE NI A L'HUMIDITE.
MAINS INPUT
CAUTION: FOR CONTINUED PROTECTION AGAINST FIRE HAZARD REPLACE ONLY WITH SAME FUSE TYPE AND RATING. REFER TO TYPE LABEL FOR FUSE RATING.
ATTENTION: AFIN D'ASSURER UNE PROTECTION PERMANENTE CONTRE LES RISQUES D'INCENDIE REMPLACEZ UNIQUEMENT PAR UN FUSIBLE DE MEME TYPE ET VALEUR. CONSULTEZ LA PLAQUE DE MARQUAGE.
~ LINE: 85-264V / 50-60Hz
CLASS 1 EQUIPMENT. MUST BE EARTHED!
1
2
5
3
4
CH1
CH2
Model: GE 234
Serialnr.: GE234-02AA-0001
Date of manufacture: 28.08.02
Made in Belgium, EU
Power requirements: 85-264V AC 50/60Hz 20W
FUSE: T 315 mA / 250 V

1. Balanced input XLR-3. The input impedance is 20K Ohm balanced or 10K unbalanced. Each input leg has the same impedance to ground to maximise input common mode rejection ratio, independent of source impedance. The maximum overload level of the input circuitry is +21dBu. Pin 1 of the input connector is connected to chassis ground. Pin 2 is the non-inverting (positive,) pin 3 the inverting (negative) input, conform international standards.
2. Balanced output XLR -3. The output impedance is 100 Ohm balanced or 50 Ohm unbalanced. The output can drive +21dBu into 600 Ohm with low distortion. Pin 1 is connected to chassis ground. Pin 2 is the non-inverting (positive,) pin 3 the inverting (negative) input, conform international standards.
3. Mains inlet and fuseholder. The mains connector is a standard 3 pin IEC connector. The centre terminal is directly connected to the chassis of the unit and must be connected to the earth terminal of the mains outlet. This is important for your safety. The mains cable supplied with this unit is a universal European model. Use only the polarised mains plug option together with a polarised receptacle. This unit is equipped with a single pole disconnect device (fuse) in the phase wire. If an unpolarised mains connection is used the receptacle the unit is connected to must be equipped with a two pole disconnect device (fuse) of appropriate rating. In case the mains plug on the mains cable is not conform to your local standard, you will need to replace it with a suitable one. In this case it is very important to respect the colour coding of the wires:

   yellow/green : earth ground
   brown or black : phase (live)
   blue : neutral

   The mains fuse is a standard 5x20mm fuse. Rating is indicated on the type label on the back of the unit. The fuse drawer can easily be opened with a flat tip screwdriver. For safety reasons, the mains cable must be removed before the drawer can be opened. Replace only with the same fuse type and rating. The auto-ranging power supply of the GE series guarantees trouble free operation all over the world, independent of local mains conditions. Acceptable mains voltages are in the range from 85 to 264 Vrms 50/60Hz. When mains power is removed, the unit automatically switches to the bypass mode, hardware linking the input to the output by means of the fail-safe relay.
4. The screws on both sides of the mains inlet are essential for the safety of the unit. These screws connect the earth pin of the mains connector to the chassis. These screws must be well tightened at all times.
5. (GE134 only) 15pin SubD system connector. This connector integrates the equaliser in the optional Q4audio equaliser drawer.

Speci fications

Inputs:
- Type: Electronically balanced. Transformer balancing optional.
- Input impedance:10KOhm. Equal impedance for + and - legs.
- Maximum input level: +21dBu.
- Input connector: XLR-3F
  Pin 1 Floating
  Pin 2 Signal + (hot)
  Pin 3 Signal - (cold)

Outputs:
- Type: Electronically balanced and floating, simulating transformer output. Active transformer balancing optional.
- Output impedance: 100 Ohms / 50 Ohms each leg.
- Maximum output level: +21dBu into 600 Ohms or greater.
- Output connector: XLR-3M
  Pin 1 Ground
  Pin 2 Signal + (hot)
  Pin 3 Signal - (cold)

General performance:
- Frequency response: ±0.5dB, 20Hz-20KHz (all controls flat).
- THD: <0.005%, 20Hz-20KHz.
- Noise: <-93dBu, 22Hz-22KHz unweighted, graphic equaliser in circuit 0dB settings.
- Channel separation: > 80dB 20Hz-20KHz (GE234).
- Level meter display: 8 led average calibrated peak responding headroom indication in 3dB steps. Clip led lights for approximately 200ms if the instantaneous peak voltage at any potential overload point in the unit comes within 1 dB of clipping, independent on level display routing switch position.
- Dynamics control: Continuously variable ±12dB of gain shift lowers noise floor by 12dB or increases headroom by 12dB. Changing the DYN control settings will change overall gain of the unit by no more than ±0.5dB (±0.3dB typical).

Filters:
- Graphic equaliser: 30 near ISO centre frequencies 25Hz-20KHz 1/3 octave.
  Graphic filters centre frequency tolerance < 5%.
  Max boost/cut: switcheable 6 or 12dB ±0.5dB reciprocal.
  Graphic equaliser switcheable in/out of signal path.
- High pass filter: 15Hz-300Hz frequency range.
  Butterwort maximally flat 12dB/octave response.
  Switcheable in/out of signal path.
- Low pass filter: 2KHz-40KHz frequency range.
  Butterwort maximally flat 12dB/octave response.
  Switcheable in/out of signal path.
- Shelving filters: 6dB of boost and cut at 100Hz and 14KHz. 6dB/octave slope.

Power requirements
- Voltage: 85V-264V 50/60Hz.
- Consumption: 12VA (GE134), 20VA (GE234).
- Connector: IEC 3 pin.

Dimensions:
- GE134: 420mm (482.6mm with 19" mounting brackets) wide x 88.9mm high x 55mm deep.
- GE234: 420mm (482.6mm with 19” mounting brackets) wide x 133.3mm high x 55mm deep.

Weight:
- GE134: Shipping: 3.1kg; Net: 2.4 kg.
- GE234: Shipping:4.0 kg; Net: 3.3 kg.

Standards:
- Safety: EN60065
- EMC: EN55103-1/EN55103-2/E2/E3

Warranty

SUMMARY

The Q4audio division of Summit Engineering nv Tongersesteenweg 190 3800 Sint-Truiden Belgium, the creators and manufacturers of the Q4audio product line warrants to you, the original purchaser and any subsequent owner of this Q4audio product, for a period of 2 (two) years (warranty period) from the date of purchase by the original purchaser that the product is free of defects in components and factory workmanship. The date of purchase is the date appearing on the first end-user's sales receipt or other proof of original purchase from an authorised Q4audio dealer.

ITEMS EXCLUDED FROM WARRANTY

This Q4audio warranty does not cover product failure caused by misuse, accident or neglect. Nor shall it be applicable to any product on which the serial number has been defaced, altered or removed. This warranty shall be considered void if this product is subjected to repair work or alteration by persons other than authorised by Q4audio in such a manner as to injure, in the sole judgment of Q4audio, the performance, stability, reliability or safety of this product. This warranty does not apply to finish or appearance items. This warranty is in effect only during the warranty period.

OUR COMMITMENT

During the warranty period, Q4audio will remedy any defect (except as excluded) by repair or at its option replacement or refund. In case of refund the defective or malfunctioning product shall be made available to us free and clear of all lies or other encumbrances. The refund will be equal to the original purchase price less a reasonable depreciation of 10% per year from the date of purchase. The refund will not include interests, insurance, closing costs, loss of profit or other financial costs that may be the result of the product's defect.

OBTAINING WARRANTY SERVICE

You must notify us of your need for warranty service, preferably by filling out the service request form in this manual and returning it to us. We will give you notice of the authorised service center to whom you may deliver the product or we will give you an authorisation to return it to the factory. All components must be shipped in a factory pack, shipping prepaid. Repairs and replacement parts provided under the terms of this warranty shall carry only the unexpired portion of this warranty.

DISCLAIMER

Q4audio is not liable for any damage to other products such as speakers, amplifiers or any other equipment that is caused by using this Q4audio product.

PRODUCT CHANGES

We reserve the right to change the design on any product without prior notice and with no obligation to make corresponding changes in products previously manufactured.

GE134 Dimensions



GE234 Dimensions